



Create pass through 14 feet wide by 16 feet high

Remove double 3-0 door and infill

Remove door and infill 2 doors.
Re-install Door along East wall
Demo 12 feet of floor to ceiling wall including Power and data back to the nearest Junction box.

Linear feet of sheet rock wall demo-105 feet.
Linear feet of door infills-30 feet.
Linear feet of 7 foot high walls- 70 feet.
Linear feet of floor to ceiling walls-650 feet
New doors and frames-16
Infill and move existing doors and frames-4

Demo top of case work Replace with Corian type Re-face all Formica on inner side of cabinet.

Walls to be floor to ceiling, insulated tied into the grid. Each area to have new 3-0 by 7-0 solid wood door to match Existing in the space. Next to each door will be a 3 foot by 7 foot reight Framed in. Each closed in office space to have 1 supply and 1 return HVAC for proper ventilation.

Demo 26 feet of sheet rock floor To ceiling wall. Repair ceiling tile and grid if needed. Relocate Fire extinguisher.

Wall within the lines to be 7 feet Height. 48 inch opening with no Door.

Demo existing 38 foot half wall

7 foot wall. No door in Opening leading to next wall.

Install wall and 3-0 door

Remove and re-install existing Doors 1 South to West. 1 North to East. Infill openings.

Demo existing floor to ceiling Wall. Include demo of electrical and data to the nearest junction Box. Relocate HVAC control Infill East door. Change existing door Right hand swing. Remove all wall Paper in the area and prep for paint.